

# 250000CPH LED Chip Mounting Machine 68 Nozzles SMT PCB Assembly Machine

# **Basic Information**

- Place of Origin:
- Brand Name:
- Certification:
- Model Number:
- Minimum Order Quantity: 1 set
- Packaging Details:
- Delivery Time:
- Payment Terms:
- Supply Ability:



# **Product Specification**

- Warranty:
- Applicable Components:
- Name:
- Application:
- Condition:
- Mounting Speed:
- Type:
- Usage:
- Highlight:

1 Year	
--------	--

CHINA

ETON

HT-F9

T/T

CE, CCC, SIRA

50 sets per month

vacuum adsorption, wooden packing

30 days after receive the down-payment

- 0805,0603,1206
- SMT Pick And Place Machine
- SMT Production Line
- New,100% Original,Brand-new
- 250000 CPH
- Automatic
- SMT Mounting Machine, LED

68 nozzles led chip mounting machine, 250000CPH led chip mounting machine, 68 Nozzles SMT PCB Assembly Machine



# More Images



## High efficiency Full-automatic 250000 CPH pick and place machine for Led tube/strip /panel lamp

### The function of highspeed led mounting machine

The function of led chip mounter machine is mounting the components(led chip/ resistor/ capacitor/ ic/ shaped components etc) on the PCB. The led chip mounter machine is the main equipment in the SMT line, and also it influence whole SMT line capacity.

### The features of ETON highspeed led mounting machine

Apply to the 0.6m, 0.9m,1.2m rigid PCB and 0.5m,1mLED flexible strip. Producing with 4 types materials at the same time with high capacity, available for board with any proportion of LED chip and resistor.

Dual arm four module, 17 nozzles for each mounting part, part A/B/C/D can be mounted separately or synchronously.

Calibration automatically, high precision, available for RGB.

Exclusive patent technology:Group to take and group to mount. smt assembly equipment

#### Machine parameter

Model	HT-F9
Dimension(L*W*H)	2700*2300*1550mm
Weight	1700kg
PCB length width	Max:1200*330mm;Min:100*100mm
PCB thickness	0.5~5mm
Mounting precision	±0.02mm
Mounting mode	Group to take and group to mount
Mounting height	≤5mm
Mounting speed	250000 CPH
Power consumption	6KW
No. Of feeders station	68 PCS
No. Of head	68 PCS

### Application

Apply to the 0.6m,0.9m,1.2m rigid PCB and 0.5m,1m Led flexible strip.

F9 as the high speed mounter machine , widely apply to many kind of led linear module, such as the strip light, panel light, tube light, etc.



#### After sales service

- Free installation:provide free installation to ensure smooth production
- e. Free warranty:1 year warranty factory service ,during the period, free replacement of spare parts
- Free training:professional training of operating and maintenance
- Free Technical Support:7\*24 hours technical online support
- Free software upgrade:offer free software upgrade whole lifetime.

### **INDUSTRIAL PARK**

We have our own industrial park, equipped with and advanced processing and manufacturing center, strict quality control, and standardize production, streamline production processes. and there is the fastest machine in the world, the capacity reach 50W CPH.



## **Shipping and Delivery**

By air, for sample and small package By sea, for large package and quantity; Other ways as customer requested. Delivery Time: Within 30 Days.

# Professional and standard packaging



Step one:Pack the machine with foam cotton and stretch film to protect the outside of the machine



# Step two:Vacuum packagingVacuum packaging; put the desiccant in a vacuum bag to prevent moisture; use straps to secure the machine;



step three: professional wooden box packaging

### **Related machine**

We can provide a whole SMT production line,led light production line:

1. Pick and place machine

2. Loader machine



Certificates

3. Conveyor machine



### Attention

1.Before using the Pick and Place machine.you must understand the basic parameters of the placement machine,

2.Before running the Pick and Place machine, the operator should do a comprehensive inspection of the machine

3. According to the boot operation sequence to implement the Pick and Place machine, there must have a detailed machine operation instructions

4.It is necessary to conduct regular troubleshooting and maintenance work on the Pick and Place machine in a timely manner

### FAQ

### Q:What is the delivery date?

A:We will deliver the machine after 30 days' deposit.

### Q:How about your system?

A:The operating system is Windows 7. The software is developed independently. It supports Chinese and English operation interface.

### Q:How is your warranty?

A:Standard warranty is one year, during warranty, any parts need to be repaired and replace will be free.

## Q:How is your training?

A:We will send our engineer to your factory to install machine and training freely.

### Contact David

Whatsapp/Wechat: +86 13827425982 E-mail: david@eton-mounter.com

